



# Infragold IHG10W/B/G







Get In Touch

Call: <u>0845 6880112</u>

Email: info@adremit.co.uk





## ASSEMBLY AND OPERATING INSTRUCTIONS

Dear Customer, please read the following information carefully before using the appliance for the first time for your own safety and to ensure correct use.


## **SAFETY INFORMATION**

- Only connect the appliance to a properly installed socket-outlet with earthing contact. Possibly a slow-blow C-fuse is necessary if you experience problems by switching on to overloaded fuses.
- Only connect the appliance to a.c. mains as specified on the rating plate.
- Never touch live parts! Danger to life!
- Never operate the appliance with wet hands! Danger to life!
- Never use the appliance if the appliance or cord is damaged. Risk of injury!
- Do not store or use any flammable materials or sprays in the vicinity of the appliance when the appliance is in use. Fire hazard!
- Do not use the appliance in flammable atmospheres (e.g. in the vicinity of combustible gases or spray cans)! Explosion and fire hazard!!
- Important! Do not insert any foreign objects into the appliance openings! Risk of injury (electric shock) and damage to the appliance!
- Attention! Do not look longer time into the light!
- Attention! The unit complete becomes very hot when the appliance is in use! Place the appliance so that it cannot be touched by accident. Risk of burns!
- Do not place any items of clothing, hand towels or similar over the heater to dry. Risk of overheating and fire hazard!
- The swivel bracket must not be adjusted while the appliance is in use! Risk of burns! Allow the appliance to cool down before adjusting the bracket
- The appliance is not intended for use by young children or infirm persons without supervision! Young children should be supervised to ensure that they do not play with the appliance!
- The socket-outlet must be accessible at

- all times to enable the mains plug to be disconnected as quickly as possible!
- These instructions for use belong to the appliance and must be kept in a safe place. When changing owners, these instructions must be surrendered to the new owner!
- The appliance must be allowed to cool down before being carried and stored!

## **LOCATION**

- The radiating element is designed for walland ceiling type operation with permanent connection and must be installed at least 1,8 m above the ground!
- The appliance should only be used mounted horizontally on a wall.
- A minimum distance of 150 cm must be maintained between the front grille and flammable items (e.g. curtains), walls and other structures.
- The appliance must not be mounted directly on flammable materials.
- The equipment should never be placed nor mounted directly under a wall socket!
- As the appliance radiates heat, no objects such as furniture should be placed between the appliance and the person using the appliance!
- The heater should never be installed face down



# **POWER CORD**

- The power cord must not come into contact with hot appliance parts!
- Never pull the plug out of the socket at the cord! Never move the appliance by pulling at the cord or use the cord for carrying purposes!
- Do not coil the cord around the appliance!

  Do not use the appliance with the cord

  coiled!
- Do not crush the cord or drag it over sharp

2



**Get In Touch** 

**Call:** 0845 6880112

abla

Call: <u>0845 6880112</u>

Email: info@adremit.co.uk

**Our Address** 





edges or place it over heated hotplates or naked flames!

#### **INSTALLATION**

- The appliance should be fitted and connected by a qualified electrician.
- Prior to starting any electrical work, the voltage must be switched off to make sure that the wiring is dead!

Only switch on the appliance when installation is complete.

#### SWITCHING ON FOR THE FIRST TIME

 After switching on the appliance for the first time and following extended periods on non-use, the appliance may smell for a short time.

#### **CLEANING**

- First, disconnect the equipment from the power supply system!
- After the appliance has cooled down, the housing can be wiped dry.
- Do not touch the quartz rods with your fingers, since stains could build up from such a contact.
- The reflector should be cleaned regularly
- Do not use any abrasive or caustic cleaning agents!
- Never immerse the appliance in water! Danger to life!

## **AFTER-SALES SERVICE**

- All repairs must be referred to authorised personnel! Therefore, you should contact your specialized dealer or the customer service. Important! Any tampering with the appliance will invalidate the warranty.
- Repairs carried out improperly and by unqualified persons may have serious consequences for the user!

#### **TECHNICAL DATA**

Rated voltage: 230 V/50 Hz Rated output: 1000W

Dimensions (LxWxD): 46,4x9,5x12,5 cm

Weight about: 2,1 kg Protective system IP44



Our Address

**Get In Touch** 

3



Main office

Frico AB Tel: +46 31 336 86 00

Box 102

SE-433 22 Partille mailbox@frico.se Sweden www.frico.se

For latest updated information and information about your local contact: www.frico.se

( (



**Get In Touch** 

**Call:** 0845 6880112

Email: info@adremit.co.uk