




#### MASTER FARM - COWS PROJECT



The MASTER FARM System communicates with:

- N°2 Global control box
- N° 2 XP-L20 control box
- N°2 XP-L22 control box
- Up to 20 Brushless motors



Rappresentative diagram RS-485





**Get In Touch** 

**Call:** 0845 6880112


Email: info@adremit.co.uk






#### **DIMENSIONS:**

#### **MATERIAL: Stainless steel**









Power 220 V

## Features of the Touch Screen Monitor POWER SUPPLY

Power 24 v Dc

Max consumption 0.6 A

#### RESISTANCE HUMIDITY LEVEL

**Working** 10%....80%

#### **INPUT**

Network RS-485 default

Protocol Modbus Standard

#### **OUTPUT**

Gate 1 Ethernet

Gate 2 USB

## 



**Get In Touch** 

**Call:** 0845 6880112

Email: info@adremit.co.uk






#### PRESENTATION SCREEN



Max/Min Speed Modbus
Limit Modbus
Type Password



SELECT TYPE OF INSTALLATION



In order to enter into the Speed limit or Modbus address page, it is required a password (10 as dafault)

## 



**Get In Touch** 

**Call:** 0845 6880112

Email: info@adremit.co.uk

**Our Address** 

Puravent, Adremit Limited, Unit 5a, Commercial Yard, Settle, North Yorkshire, BD24 9RH





#### **ENABLE/DISABLE MOTORS WITH THEIR ADDRESS**





SET THE MAXIMUM AND MINIMUM SPEED FOR EACH MOTOR (RPM)



**PER USCIRE** 

## 



**Get In Touch** 

**Call:** 0845 6880112


 $\square$ 

Email: info@adremit.co.uk













**Get In Touch** 

Call: <u>0845 6880112</u>

Email: info@adremit.co.uk








## Page brushless motors



Write the number of the motor that you want to see



www.evelsrl.it

**Evel Srl** 





😲 Via Luigi Albertini 36 - Edificio D5 I-60131 Ancona 🔪 Tel. +39 071 2865015 🏻 www.evelsrl.it 🔀









**Get In Touch** 

Call: <u>0845 6880112</u>



Email: info@adremit.co.uk







## GLOBAL/F8 **HOME PAGE**



www.evelsrl.it







😲 Via Luigi Albertini 36 - Edificio D5 I-60131 Ancona 🔪 Tel. +39 071 2865015 🌘 www.evelsrl.it 🖂 info@evelsrl.it









**Get In Touch** 

Call: <u>0845 6880112</u>



Email: info@adremit.co.uk





#### **VENTILATION PAGE**





Page ventilation GLOBAL/F8

#### **LEGEND:**

- **SET VENT:** starting temperature of the ventilation
- MIN SPEED: % min rpm of the fan
- MAX SPEED: % max rpm of the fan
- **B-PROB:** range in °C to pass from min to max rpm
- START: % of rpm at the startup machines
- T.H.I.: Active/disactive perceived temperature
- **T.ON:** machine starting time
- **T.OFF:** machine shutdown time
- **SPEED:** % actual speed







**Get In Touch** 

**Call:** 0845 6880112



Email: info@adremit.co.uk





#### SPRINKLERS PAGE





Page showers GLOBAL/F8

#### **LEGEND:**

- **SET H2O:** starting temperature of sprinklers
- **ACTIVE:** active/disactive sprinklers
- TIME START: sprinklers starting time
- TIME STOP: sprinklers shutdown time
- **RELATION:** on/off to link with the ventilation temperature
- **OFF-SET:** difference of temperature with the ventilation
- **N.B.:** sprinklers hysteresis
- **LIMIT:** % early deceleration time of the fan at the opening of the sprinklers
- T.DECEL: indicate how many seconds before the sprinklers starting, slowing down the fan
- **BLO-VENT:** on/off block ventilation at the sprinklers starting
- T.ON1 T.ON2 T.ON3 T.ON.4: duration in seconds of each configuration
- T.OFF1 T.OFF2 T.OFF3 T.OFF.4: break in seconds between two starting of the same configuration
- DT.2 DT.3 DT.4: ranges in temperature degrees to which to start the configurations of the sprinklers







**Get In Touch** 

**Call:** 0845 6880112

 $\square$ 

Email: info@adremit.co.uk





#### **HUMIDITY PAGE**





Page umidity GLOBAL/F8

#### **LEGEND:**

- **SET RH%:** Set the Humidity at which the spriklers stop working
- **BLOCK H2O:** Active/disactive sprinklers when the humidity set is reached
- **ACTIVE R.:** active/disactive optional relay
- **N.B.:** relay hysteresis

#### **WIND PAGE**





Page wind GLOBAL/F8

www.evelsrl.it

**Evel Srl** 







🕐 Via Luigi Albertini 36 - Edificio D5 I-60131 Ancona 🔪 Tel. +39 071 2865015 🌘 www.evelsrl.it 🔀 info@evelsrl.it

f 🔰 18+1 🏭 in 1910



**Get In Touch** 

Call: <u>0845 6880112</u>



Email: info@adremit.co.uk





#### **LEGEND:**

- **SET WIND:** set the wind speed at which the ventilation stops working
- **DELAY:** waiting time before restarting the ventilation after windy conditions
- **BLO.VENT.:** active/disactive block of the ventilation
- **N.B.:** anemometer hysteresis



#### **CLOCK PAGE**





Page time GLOBAL/F8

#### **LEGEND:**

- **CLOCK:** on/off system timed switching on
- **SET CLOCK FUNCTION:** 1 or 2 timed switching
- **CLOCK 1 E CLOCK 2:** first and second switching
- **SET FROM:** start-up time
- **SET TO:** shutdown time







**Get In Touch** 

**Call:** 0845 6880112

**A** E

Email: info@adremit.co.uk





#### **ALARM PAGE**





Page alarm GLOBAL/F8

#### **LEGEND:**

- **SET MAX:** set max temperature alarm
- **SET MIN:** set min temperature alarm







**Get In Touch** 

**Call:** 0845 6880112

Email: info@adremit.co.uk





#### **RECORD PAGE**





Page record day GLOBAL/F8

#### **LEGEND:**

• **RECORD DAY:** on this screen are recorded every 15 min. the following data: Temperature, Humidity, Wind Speed, THI





Page record story GLOBAL/F8

#### LEGEND:

• **RECORD DAY:** in this screen are saved all the measurements taken previously. Storing up to 1000 day of: Max / Min Temp, Max / Min Humidity, Max / Min Wind Speed, Max / Min THI







**Get In Touch** 

Call: <u>0845 6880112</u>

 $\bowtie$ 

Email: info@adremit.co.uk







## **XP-L20 HOME PAGE**



www.evelsrl.it







😲 Via Luigi Albertini 36 - Edificio D5 I-60131 Ancona 🔪 Tel. +39 071 2865015 🌘 www.evelsrl.it 🖂 info@evelsrl.it









**Get In Touch** 

**Call:** <u>0845 6880112</u>

Email: info@adremit.co.uk





### **VENTILATION PAGE**





Page ventilation XP-L22

#### **LEGEND:**

- **SET VENT:** starting temperature of the ventilation
- MIN SPEED: % min rpm of the fan
- MAX SPEED: % max rpm of the fan
- **B-PROB:** range in °C to pass from min to max rpm
- START: % of rpm at the startup machines







**Get In Touch** 

**Call:** 0845 6880112

Email: info@adremit.co.uk





#### **SPRINKLERS PAGE**





Page showers XP-L22

#### **LEGEND:**

- **SET H2O:** starting temperature of sprinklers
- **N.B.:** sprinklers hysteresys
- LIMIT: % early deceleration time of the fan at the opening of the sprinklers
- T.DECEL: indicate how many seconds before the sprinklers starting, slowing down the fan
- **BLO-VENT:** on/off block ventilation at the sprinklers starting
- T.ON1 T.ON2 T.ON3 T.ON.4: duration in seconds of each configuration
- T.OFF1 T.OFF2 T.OFF3 T.OFF.4: break in seconds between two starting of the same configuration
- DT.2 DT.3 DT.4: ranges in temperature degrees to which to start the configurations of the sprinklers







**Get In Touch** 

**Call:** 0845 6880112

 $\square$ 

Email: info@adremit.co.uk





#### **RECORD AND ALARM PAGE**





Page alarm XP-L22

#### **LEGEND:**

- SET MAX: set max temperature alarmSET MIN: set min temperature alarm
- Page record day

  XP-L22

  FR

  RECORD

  RECORD

  PAGE record story

  XP-L22

  FR

  RESURD

  RE

#### **LEGEND:**

RECORD DAY: on this screen are recorded every
 15 min. the following data: Temperature, Wind
 Speed

#### LEGEND:

 RECORD DAY: in this screen are saved all the measurements taken previously. Storing up to 1000 day of: Max / Min Temp, Max / Min wind speed

# www.evelsrl.it Evel Srl Via Luigi Albertini 36 - Edificio D5 I-60131 Ancona Tel. +39 071 2865015 www.evelsrl.it info@evelsrl.it info@evelsrl.it www.evelsrl.it cod. Fisc. & P.IVA 02687550422 - Numero Iscrizione Registro Imprese AN 02687550422 - R.E.A. di Ancona: 207278 - Cap. Soc. € 10.000,00 i.v.



**Get In Touch** 

**Call:** 0845 6880112


**Z** Email: <u>info@adremit.co.uk</u>







## **EVENT HOME PAGE**



#### **LEGEND:**

• **EVENT:** on this screen are stored all the alarms occurred to the inverter, motor and connection Modbus RS-485, with date, time and the equipment involved.





**Get In Touch** 


**Call:** 0845 6880112

Email: info@adremit.co.uk





## **Segnal 0-10 V Electric connections**



Www.evelsrl.it

Evel Srl

Via Luigi Albertini 36 - Edificio D5 I-60131 Ancona Tel. +39 071 2865015 www.evelsrl.it info@evelsrl.it info@evelsrl.it www.evelsrl.it info@evelsrl.it Cod. Fisc. & P.IVA 02687550422 - Numero Iscrizione Registro Imprese AN 02687550422 - R.E.A. di Ancona: 207278 - Cap. Soc. € 10.000,00 i.v.



**Get In Touch** 

Call: <u>0845 6880112</u>

Email: info@adremit.co.uk